# INSTALLATION INSTRUCTIONS FOR 10281-860 FOR WALL SCONCE

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DO DISJONCTEUR

#### **PREPARATION**

- 1. Shut off power at the fuse box or circuit breaker box. If necessary remove the old fixture and mounting hardware.
- 2. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any small parts necessary for installation.

#### **MOUNTING THE FIXTURE (FIG. 1)**

Attach the mounting plate (A) to the junction box (not included) using the mounting screws (C) (Size: 8-32\*1/2"
 L). The side of the mounting plate (A) marked "GND" must face out.

## **CONNECTING JUNCTION BOX WIRES (FIG. 2)**

- 4. Connect the electrical wires as shown in Fig.2, making sure that all wire nuts are secured. If your junction box has a ground wire (green or bare copper), connect the fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to the mounting plate (A) using the green screw (B) provided.
- 5. Tuck the wire connections neatly into the junction box.

### **COMPLETING THE INSTALLATION (FIG. 1)**

- 6. Align the back plate (E) onto the mounting plate (A) and secure with screws (D).
- 7. Install (1) one candelabra base bulb up to 60 watts each or CFL or LED equivalent (Not included), in accordance with the fixture specification (DO NOT EXCEED THE MAXIMUM WATTAGE RATING!) (NE PAS DEPASSER LA PUISSNCE NOMINALE MAXIMALE!)
- 8. Align the cloth shade (F) onto the arm (G) and secure with screws (H).

Your installation is now complete. Return power to the junction box and test the fixture.

**IMPORTANT:** Fixture should be installed by a qualified electrician to ensure proper wiring and installation.







