WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER. AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

ASSEMBLY THE FIXTURE (FIG. 1)

- Shut off the power at the fuse box or circuit breaker. If necessary, remove the existing fixture and its mounting hardware from the ceiling.
- Carefully unpack your new fixture and lay out all the parts in a clear area. Take care not to lose any small parts necessary for installation.
- 3. Adjust the fixture arms to its desired position.
- 4. Assemble the shade (E) onto the bracket (F) using the thumb screw (D) well.
- 5. Thread the stem (I) into the coupling (G) tightly.
- Install the bulb (not included) in accordance with the fixture's specifications. (DO NOT EXCEED THE MAXMUM WATTAGE RATING!) (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!).
- 7. Thread the nipple (I) into coupling (H), and secure with hex nut.
- 8. Put the tube (J), tube cover (N), rubber washer (O), glass diffuser (P), rubber washer (O), steel washer (R) over the nipple (I) in order, and secure with hex nut (S) well.
- Put the cover (T), rubber washer (U), crystal ball (V), rubber washer (U), tube (X) over the nipple (I) in order and secure with nut (Y).
- Attach the mounting bar (M) to the outlet box using the outlet box screws (K). The side of the mounting plate marked "GND" must face out.
- 11. Follow the wiring instructions carefully (See Fig.2).
- 12. Attach the fixture main body onto outlet box by protruding mounting screws (L) through mounting holes on the canopy (A) and secure with ball nut (B).

CONNECTING THE WIRES (FIG. 2)

- 13. Connect the electrical wires as follows. Connect the smooth wire from the fixture to the smooth (HOT) house wire. Connect the ribbed wire from the fixture to the ribbed (Neutral) house wire. Make sure all the wire nuts were secured. You may wrap the connections with electrical tape. If your outlet box has a ground wire (Green or Bare Copper) connect fixture's ground wire to it. Other wise attach the bare copper fixture wire to the green ground screw on the mounting bar.
- 14. Tuck the wire connections neatly into the ceiling junction box.

Your installation is now complete. Turn on the power supply of the junction box to test the fixture.







