INSTALLATION INSTRUCTIONS

Item# 19955-860 (New. 2025/09/07)

READ AND SAVE THESE INSTRUCTIONS

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER. VERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

ASSEMBLING THE FIXTURE (Fig. 1)

- 1. Shut off power at the fuse box or circuit box and remove the old fixture including the mounting hardware.
- Carefully unpack your new fixture and lay out all the parts in a clear area. Be careful Not to misplace any small parts necessary for installation.

HANGING THE FIXTURE (Fig. 2)

- 3. Take Mounting Plate (B) assembly and mount to junction box (not included) with mounting screws (G). The side of Mounting Plate (B) marked with "GND" must face out.
- 4. In order to Pull the wire further up through Cord grip (E) into the ceiling outlet box, you will need to cut the braid with the help of a fine nose scissors. Once the braid is cut to desired length, secure with tape to seal loose ends. Lock the cord (F) with Cord Grip (E).
- 5. Pull wire from Ceiling junction box to make electrical connections with wire.

CONNECTING THE WIRE (Fig. 3)

- 6. Connect the electrical wire as shown in Fig.3, making sure that all wire connectors are secured. If your outlet box has a ground wire (green or bare copper), connect the fixtures ground wire to it. Otherwise, connect the fixture ground wire directly to the crossbar using green screw (H) provided.
- 7. Tucking the wire in the Junction Box.
- 8. Install the canopy (A) via canopy screw (D).

FINISHING THE FIXTURE (Fig.1)

 Install (1) one G40 base bulbs (I) up to 100 watts Type A or or CFL or LED equivalent (not included) in accordance with the Fixture (L) specification—DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!).

Your installation is now complete. Return power to the outlet box and test the fixture.

Note: Illustration (Fig. 1) on this manual is for installation purposes only. It may or may not be identical to the fixture purchased.







