## INSTALLATION INSTRUCTIONS

Item#N7353-790 (New. 2023/7/06)

### **READ AND SAVE THESE INSTRUCTIONS**

# **W**ARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

### AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

#### PREPARATION (Fig. 1 & Fig. 4)

- 1. Shut off power at the fuse box or circuit breaker box and remove the old fixture including the mounting hardware.
- 2. Carefully unpack your new fixture and lay out all the parts in a clean area. Take care not to misplace any small parts necessary for installation.
- 3. The arms have been placed to lay flat for shipping. Adjust arms to proper position. (See Fig. 4)

#### ASSEMBLING THE FIXTURE (Fig. 1 & Fig. 2)

- 4. Thread stem (G) onto all thread (H) of socket assembly (L).
- 5. Thread swivel (E) of upper assembly onto stem (G).
- 6. Carefully place bolts (F) through holes on top of frame assembly (J). Then tighten with plastic washer and finial (K).
- Place mounting plate (A) to junction box (Not included) using mounting screws (B) (Size: #8-32N\*L0.5"). The side of mounting plate marked "GND" must face out.
- 8. The support cable is provided to support weight of fixture while wiring. Align fixture to mounting plate (A) and attach hook (M) on end of support cable (N) into a slot located on mounting plate (A). Carefully allow support cable (N) to support weight of fixture while wiring.

#### **CONNECTING THE WIRES (Fig. 3)**

- 9. Connect the electrical wires as shown in Fig. 3, making sure that all wire connectors are secured. If your junction box has a ground wire (green or bare copper), connect fixture's ground wire to it. Otherwise, connect fixture's ground wire directly to mounting plate (A) using green screw provided.
- 10. Tuck wire connections neatly into junction box.

#### **COMPLETING THE INSTALLATION (Fig. 1)**

- 11. Place canopy (C) to mounting plate (A) and secure with screws (D).
- 12.Install (4) four candelabra base bulbs (I) up to 60 watts each or CFL or LED equivalent (not included) in accordance with the fixture specification.
  - —DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!).

Your installation is now complete. Return power to the junction box and test the fixture.

Note: Illustration (Fig. 1) on this manual is for installation purposes only. It may or may not be identical to the fixture purchased.







