INSTALLATION INSTRUCTIONS

For item#N7767-683 (Rev. 9/03/2021)

READ AND SAVE THESE INSTRUCTIONS WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER. AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR. PREPARING FOR INSTALLATION (Fig. 1 & Fig. 3) Fig. 1 Outlet Box (Ceiling) Shut off power at the fuse box or circuit breaker box and remove the old fixture including the mounting hardware. 2. Carefully unpack your new fixture and lay out all the parts in a Hex Nut Cross Barclear area. Take care not to misplace any small parts Lock Washer Mounting Screws necessary for installation. Place acrylic board (H) into metal bracket (J) of crossbar beam 3. All Thread and bottom sheet (P), and secure with screws (G) at both Canopy ends. Secure tube (T) to fixture body, and thread all thread of tube Ceiling loop 4. assembly through crossbar beam (F), secure with fixture loop Lock Collar (A). Quick Link 5. Attach metal plate (K) to metal bracket (J) by using screws (E). Thread all thread into ceiling loop until snug. 6. Chain (End link) Thread the other end of the all thread into crossbar until snug. 7. Note: The length of the all thread into crossbar may be adjusted if necessary. Chain (End link) 8. Use lock washer and hex nut to secure the all thread into crossbar. Quick Link 9. Take crossbar assembly and mount it to ceiling outlet box with Chain#HCH4072-GMS mounting screws (Size: #8-32N*L0.5"). The side of crossbar Fixture Loop marked with "GND" must face out. 10. Determine desired hanging height and use a pair of proper chain pliers to remove and discard the excess chain. Fig. 2 11. Open quick link and connect to fixture loop and end of chain, FIXTURE WIRES Black or Smooth FIXTURE WIRES White or then close the quick link. 12. Carefully lace fixture's wires through the chain, slip lock collar, canopy over the chain and wire, carefully let these parts rest on the fixture loop. 13. Open other quick link to connect other end link of chain to ceiling loop on canopy. Then close quick link. 14. Feed the fixture wires through loop and all thread assembly. CONNECTING THE WIRES (Fig. 2) Fig. 3 15. Connect the electrical wires as shown in Fig. 2, making sure Set# A-012 that all wire connectors are secured. If your outlet box has a F - Crossbar ground wire (green or bare copper), connect the fixture's - Ground screw ground wire to it. Otherwise, connect the fixture's ground wire Mounting Screw*2 directly to the crossbar using the green screw provided. F 16. Tuck wire connections neatly into outlet box. COMPLETING THE INSTALLATION (Fig. 3) 17. Raise canopy to ceiling and secure with lock collar to ceiling loop. 18. Place candle covers (C) over sockets (B). 19. Install (6) six candelabra base bulbs (D) up to 60 watts each or CFL or LED equivalent (not included) in accordance with the fixture specification-DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!). Your installation is now complete. Return power to the outlet box and test the fixture. Note: Illustration (Fig. 3) on this manual is for installation purposes only. It may or may not be identical Candle Cover# CCV21085P-710 Notice: It is important to use proper chain pliers (not included) To OPEN and CLOSE the chain included with this fixture. Do not open them with other tools that may twist or stress the chain links. It is important to use proper chain pliers like the ones shown in the Intertek ighting

diagram.