

Installation Instructions

For Portable Lamp

Model#P184-084

WARNING

- Risk of shock, do not plug in the unit before assembly.
- Do not exceed the maximum wattage rating (Max. 100W). (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)
- Before you begin assembly of your new fixture, please follow the instruction manual step by step.

INSTRUCTION:

1. Place all parts on a smooth, flat surface to protect the finish until ready to install.
2. Place the threaded ends of the “U” shape harp (A) through the holes of socket bars.
3. Thread the nuts (B) on threaded ends of the harp(A) until tight.
4. Put the shade (C) on the harp (A), being careful to line up the holes on the shade spider with the holes on the harp.
5. Put the finials (D) through the holes of shade spider, thread them into the holes of the harp clockwise until tight.
**IF the shade is not in a correct level position after assembled, you can adjust it if necessary by threading the nuts on feet of harp (A) higher or lower to your required level.
6. Install the Light Bulb in accordance with the lamp's specifications.
(DO NOT EXCEED THE MAXIMUM WATTAGE RATING!) (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)

IMPORTANT SAFETY INSTRUCTIONS

1. This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock.
This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the Plug.
2. This lamp use rotary on off switch on base. Please use E26 medium base , A19 100W light bulb.

**IN AN ONGOING EFFORT TO BE ENVIROMENTALLY FRIENDLY AND IN COMPLIANCE WITH CALIFORNIA TITLE 20. AN ENERGY SAVING COMPACT FLUORESCENT BULB(S)IS INCLUDED.
PLEASE NOTE THAT THE LIFE EXPECTANCY OF THE BULB(S) IS NOT GUARANTEED.**

