

# Installation Instructions

For Portable Lamp

Model#P184-084

## WARNING

- Risk of shock, do not plug in the unit before assembly.
- Do not exceed the maximum wattage rating (Max. 100W). (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)
- Before you begin assembly of your new fixture, please follow the instruction manual step by step.

## INSTRUCTION:

1. Place all parts on a smooth, flat surface to protect the finish until ready to install.
2. Place the threaded ends of harp (A) through the holes of the harp holder and secure with cap nuts (B).
3. Put the shade (C) on the harp (A), being careful to line up the holes on the shade spider with the holes on the harp.
4. Secure with finials (D) into the holes of shade spider until tight.  
\*\*If the shade is not in a correct level position after assembly, you can adjust it if necessary by threading the nuts on harp (A) higher or lower until the leveled position is reached.
6. Install (2) two medium base bulbs up to 100 watts each or CFL or LED equivalent in accordance with the fixture specification. **(DO NOT EXCEED THE MAXIMUM WATTAGE RATING!) (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)**

## IMPORTANT SAFETY INSTRUCTIONS

1. This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock.  
This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.
2. This lamp use rotary on/off switch on the lamp base.

IN AN ONGOING EFFORT TO BE ENVIRONMENTALLY FRIENDLY AND IN COMPLIANCE WITH CALIFORNIA TITLE 20 AN ENERGY EFFICIENT COMPACT LED BULB(S) IS INCLUDED.

american  
lighting  
association

