INSTALLATION INSTRUCTIONS FOR P5544-66A-L For LED Table Lamp READ AND SAVE THESE INSTRUCTIONS

ASSEMBLING THE LAMP (Fig.1)

- 1. Carefully unpack your new lamp and lay out all the parts in a clear area. Take care not to misplace any small parts necessary for installation.
- Insert the power plug (B) into base port and insert plug (C) into the socket.
- Adjust the angle of LED disk (F) to the appropriate position you desire (CAUTION: Please adjust in the direction of the arrow) (the maximum adjustment angle of the LED disk (F) is 180 degrees, please be careful not to use too much force)
- 4. This table lamp contains a dimming touch switch (D). When the blue light on the switch is on, it means the lamp has been powered on. Use this switch in the following order:
 - a: Touch the switch and the lamp will turn on.
 - b: Press and hold the switch for 3-4 seconds to adjust the brightness of the lamp.
 - c: Touch the switch again to turn the lamp off.
- 5. The lamp has one USB (E) interface, which can charge mobile phones or other electronic devices, and the output voltage is 5V.
- MAINTENANCE: Use a soft lint free cloth to clean metal frame. UNDER NO CIRCUMSTANCES SHOULD METAL POLISHES, AMMONIA BASED CLEANERS, ABRASIVES, OR AEROSOL SPRAYS BE USED.

IN AN ONGOING EFFORT TO BE ENVIRONMENTALLY FRIENDLY AND IN COMPLIANCE WITH CALIFORNIA TITLE 20 AN ENERGY SAVING INTEGRATED IS INCLUDED.





