

# INSTALLATION INSTRUCTIONS

For Models # P5747-695/084

**WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.**

**AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.**

## MOUNTING THE FIXTURE (Fig. 1)

1. Shut off power at the circuit breaker and remove the old fixture including the mounting hardware.
2. Carefully remove the fixture from the carton and check that all parts are included as shown in (Fig 1).
3. Remove mounting screws (F) (Size:#8-32 0.5") from canopy (B). Secure mounting plate (G) to outlet box (Not included) using mounting screws (D) (Size:#8-32 1"). The side of the mounting plate marked "GND" must face out.

## SUGGESTED INSTALLATION (Fig. 1)

4. Carefully feed the wires through rod (A) and secure to fixture body (C) and swivel (M) of canopy (B).

## CONNECTING THE WIRES (Fig. 2)

5. Connect electrical wires as shown in Fig. 2, making sure that all wire connectors (E) are secured. If your outlet box has a ground wire (green or bare copper), connect fixture's ground wire to it. Otherwise, connect fixture's ground wire directly to mounting plate (G) using the green screw provided.

## FINISHING THE INSTALLATION (Fig. 1)

6. Place canopy (B) over mounting plate (G) and secure with mounting screws (F).
7. Install (3) three medium base bulbs (L) up to 75 watts each or CFL or LED equivalent (not included) in accordance with the fixture specification—**DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)**.
8. Align small white metal washer (H), plastic washer (N) and glass diffuser (I) to the bottom center stem of fixture body (C).
9. Use plastic washer (N), large white metal washer (J) and cap (K) to secure the glass diffuser (I) to fixture body (C).
10. The glass diffuser (I) can be adjusted if necessary.

**IMPORTANT: FIXTURE SHOULD BE INSTALLED BY A QUALIFIED ELECTRICIAN TO ENSURE PROPER WIRING AND INSTALLATION.**

Your installation is now complete. Return power to the outlet box and test the fixture.

