MEDALLION INSTALLATION GUIDE 1940-126 1940-290 1940-299

©Minka Lighting, Inc.
This product is protected by United States Federal and/or
State Law, including Patent and/or Copyright laws.



Apply polyurethane adhesive on the back side of the medallion staying approximately 1" away from edge. (polyurethane adhesive not included)



If required, standard or trim head screws can be used to secure medallion until adhesive sets. Screw heads should be recessed. (Screws are not included)



If any adhesive runs out during steps 1 or 2, use a wet cloth immediately to remove the excess.

The medallion is now installed!



When you install the lighting fixture, you may need to replace the threaded nipple that comes with the lighting fixture, with the longer threaded nipple included with the ceiling medallion.