## INSTALLATION INSTRUCTIONS FOR P8204-044B-L

# For LED Pendant

READ AND SAVE THESE INSTRUCTIONS

# WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER AVERTISSEMENT!COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DO DISJONCTEU

Fig.1

### ASSEMBLING THE FIXTURE (Fig.1)

- 1 Shut off power at the fuse box or circuit breaker. Remove the old fixture including the mounting hardware.
- 2 Carefully remove the fixture from the carton and check that all parts are included as show in Figure 1. Unscrew (G) to remove the mounting plate (A) from the canopy (F).
- 3 Position mounting plate(A) on the ceiling ,and mark the location of the dry wall anchors(W).Pre-drill the holes for the ry wall anchors ,Insert the dry wall anchors(W) into the ceiling ,Attach the mounting plate (A) to the junction box using the mounting screws(B,size 8#-32N 1/2").The side of the mounting plate marked "GND" must face out.Place the wood screw (T) through the slot hole into the dry wall anchor(W) to secure the mounting
- 4 The support cable(E) is provided to support the weight of the fixture while wiring .Align the fixture to mounting plate(A) and attach quick link (U) on the end of support cable (E) into the hook hole on the mounting plate(A). Carefully allow the support cable(E) to support the weight of the fixture while wiring.



5 Pass the black/white and bare copper wires from the hole of the mounting plate(A). Connect the electrical wire as shown in figure 2, making sure that all wire connectors are secured. If your junction box has a ground wire (green or bare copper), connect the ground wire from the fixture to it. Otherwise connect fixture ground wire (C) directly to the mounting plate using the green screw (D)provided. Tuck the wire connections neatly into the ceiling junction box as you hold the canopy towards the ceiling.

# FIG.2 FIXTURE WIRES WHITE OR RIBBED HOUSE WIRES WIRES GREEN OR BARE COPPER (GROUND) HOUSE WIRES WIRES GREEN OR BARE COPPER (GROUND) HOUSE WIRES WIRES GREEN OR BARE COPPER (GROUND) HOUSE WIRES WIRES GREEN OR BARE COPPER (GROUND)

### FINISHING THE INSTALLATION (Fig.1)

6 Fix the canopy(F) into the mounting plate (A) with screw(G).
Adjust the length of the cable to pull or push until the desired length by pushing down the spring nut (S)

Your installation is now complete. Return power to the junction box and test the fixture.

CAUTION/ATTENTION: When handling the fixture, do not apply pressure to the LEDs. Hold the fixture by the frame only.

IMPORTANT: Fixture should be installed by a qualified electrician to ensure proper wiring and installation. Dimmable with ELV dimmer switches. Recommend model# SELV-300P Skylark



### INSTALLATION INSTRUCTIONS FOR P8204-044B-L

# For LED Pendant READ AND SAVE THESE INSTRUCTIONS

# WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER AVERTISSEMENT!COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DO DISJONCTEU

# LED module replace(Fig.3)

# Shut off power before replacing

- 1:Each alu stick there have a LED module, if any of them does not work, replace the whole stick(H) as shown in Fig.3.Make sure the power is off when you replace.
- 2:Twist-off the finial (M) to take the plate(N) down from the fixture carefully;
- 3:Find out the wire of the no work one ,disconnect the wire nut (K),cut a short section of cable wire if necessary , be careful not to damage the other insulation jacket of the inner wire when stripping bare strands of ½".
- 4:Pull-out the acrylic shade (I). Save these parts for subsequent service.
- 5:Twist-off the up and down screw(O), move away the no work one ,replace a new one .
- 6:Repeat 5-1 to assembly the fixture.

Your replace is now complete, Re-install the fixture to the ceiling as shown in Fig.1, return power to the junction box and text the fixture



