INSTALLATION INSTRUCTIONS FOR P1145-L For Wall Sconce Fixture OR Ceiling Mount READ AND SAVE THESE INSTRUCTIONS

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER AVERTISSEMENT!COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DO DISJONCTEU

ASSEMBLING THE FIXTURE (Fig.1 Fig. 2)

- Shut off power at the fuse box or circuit breaker. If necessary, remove the old fixture including the mounting hardware.
- Carefully remove the fixture from the carton and check that all parts are included as show in Figure 1.
- 3. Attach circular strap (A) to the junction box using junction boxes screws (D) (Size: 8-32*1/2"L). The side of the mounting back plate marked "GND" must face out.

CONNECTION THE WIRES (Fig.3)

module.

4. Connect the electrical wires as shown in Fig.3, making sure that all wire nuts are secured. If your outlet has a ground wire (green or bare copper), connect the fixture's ground Wire to it. Otherwise, connect the fixture's ground wire directly to the mounting plate using the green screw (B) provided. Tuck the wire connections neatly into the junction box.

FINISHING THE INSTALLATION (Fig.1 Fig.2)

- Align the backplate (E) onto joint (B) and secure with screws (F).
 Align the frame (J) and the glass (G) onto backplate (E) and secure with screws (H) and rubber washers (I). (For wall sconce, please follow the arrow located inside the backplate (E), glass (G), frame(J) marked "This side up").
- To prevent moisture from entering the outlet box and causing a short circuit, use clear caulking (i.e. Indoor/Outdoor silicone sealant) to outline the outside of fixture back plate where it meets the wall leaving a space at bottom to allow moisture a means to escape (Fig.4).

Your installation is now complete. Return power to the junction box and test the fixture.

CAUTION /ATTENTION: When handling the fixture, do not apply pressure to the LEDs. Hold the fixture by the base or back plate (E) only. **Replacing LED module (Fig.5)**

The LED module can be replaced by a qualified electrician without cutting of wire and without damage to any decorative element to which the fixture is attached. See installation steps for more details (Fig.4) Warning: Turn off power at the circuit breaker before replacing LED

- a. To remove the fixture from the wall: Loosen screws (H), and remove rubber washers (I), frame (J), glass (G) then loosen cap nuts (F). (Fig.1 Fig 2). Disconnect the wire connectors and place the fixture on a clear flat surface.
- Loosen screws (S), remove protective case (O). Remove the waterproof silicon on the protective case (O), loosen screws (M) remove cap (N) and diffuser (Q).
- Loosen screws (K2), rubber washers (R), screws (K1) and wire fastener (L). Carefully remove LED module (P).
- d. Reverse steps a-c for installing the new LED module. Note: The LED module should be provided by a specified supplier. **IMPORTANT:** Fixture should be installed by a qualified electrician to ensure proper wiring and installation.

Dimmable with ELV and/or LED compatible wall dimmer switches.













