# INSTALLATION INSTRUCTIONS

Item#1701-781

**READ AND SAVE THESE INSTRUCTIONS** 

## WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

## AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

### HANGING THE FIXTURE (Fig. 1)

- 1. Shut off power at the circuit breaker and remove old fixture including the mounting hardware.
- 2. Carefully remove the fixture from the carton and check that all parts are included as shown in the illustration.
- Secure rod (F) to top of fixture body (G) and canopy (D). Pull wires through as you go.
- 4. Thread screws (A) into the pre-drilled holes in crossbar (B) spaced the same distance apart as the holes in canopy (D). The length of screws (A) may be adjusted if necessary.
- Attach crossbar (B) to junction box (S) (not included) using mounting screws (Q) (Size: #8-32N\*L25mm). The side of crossbar (B) marked "GND" must face out.

#### CONNECTING THE WIRES (Fig. 2)

- 6. Connect the electrical wires as shown in fig 2, making sure that all wire connectors (C) are secured. If your junction box (S) has a ground wire (green or bare copper), connect the fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to crossbar (B) using green screw (R) provided.
- 7. Tuck the wire connectors neatly into junction box (S).


#### FINISH THE INSTALLATION (Fig. 1)


- 8. Slide canopy (D) over screws (A) and secure with finials (E).
- Install (3) three medium base bulbs (M) up to 60 watts each or CFL or LED equivalent (not included) in accordance with the fixture specification—DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!).
- 10. Slide metal washer (I), rubber washer (J), glass (N) and finial cap (M) over bottom center stem (H).
- 11.Use hex nut (K) and finial (L) to secure glass (N) and finial cap (M) to fixture body.

Note: Illustration (Fig.1) on this manual is for installation purposes only. It may or may not be identical to the fixture purchased.

#### IMPORTANT: FIXTURE SHOULD BE INSTALLED BY A QUALIFIED ELECTRICIAN TO ENSURE PROPER WIRING AND INSTALLATION.

Your installation is now complete. Return power to the junction box and test the fixture.







No ch

То

inc

