

# INSTALLATION INSTRUCTION

Item# N1946

## READ AND SAVE THESE INSTRUCTIONS

**WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER .**  
**AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.**

### PREPATION

1. Shut off the power at the circuit breaker box and, remove the old fixture including the mounting hardware.
2. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any parts necessary for installation.

### ASSEMBLING THE FIXTURE(Fig.1)

3. Slip all thread (E) of canopy over tube (F) and tighten all thread in coupling (G).

### MOUNTING THE FIXTURE (Fig.1)

4. Secure circular strap (A) to the junction box (Not provided) with junction box screws (B) (Size: #8-32\*0.6"L), through the slotted holes in the circular strap (A). Make sure the side of circular strap marked "GND" must face out.

### CONNECTING THE WIRES (Fig.2)

5. Connect the electrical wires as shown in Fig.2, making sure that all wire connectors are secured. If your junction box has a ground wire (green or bare copper), connect the ground wires to it. Otherwise, connect the ground wire directly to the circular strap (A) using the green screw provided.
6. Tuck wire connectors neatly into the junction box (Not provided).

### COMPLETING THE INSTALLATION (Fig. 1)

7. Raise the canopy (D) to the circular strap (A), and secure with mounting screws (C) (Size: #8-32\*0.5"L).
8. Install (8) eight candelabra base bulbs up to 60 watts each or CFL or LED equivalent (not included) in accordance with the fixture specification. (**DO NOT EXCEED THE SPECIFIED WATTAGE!**) (**NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!**)
9. Install the crystal glass (J & K) onto the fixture body and secure with the screws (I) using wrench (H) (Provided). Don't over tighten.

**NOTE: When installing screws (I), it is necessary to leave 1-2 millimeters outside.**

Your installation is now complete. Return power to the junction box and test the fixture.

