INSTALLATION INSTRUCTIONS

For Models # P5747-695

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

MOUNTING THE FIXTURE (Fig. 1)

- 1. Shut off power at the circuit breaker and remove the old fixture including the mounting hardware.
- 2. Carefully remove the fixture from the carton and check that all parts are included as shown in (Fig 1).
- Remove mounting screws (F) (Size:#8-32 0.5") from canopy (B). Secure mounting plate (G) to the junction box (not included) using mounting screws (D) (Size:#8-32 1"). The side of the mounting plate marked "GND" must face out.

SUGGESTED INSTALLATION (Fig. 1)

4. Thread rod (A) to all thread of fixture body (C) and secure swivel (M) of canopy (B) to rod (A). Carefully feed the wires through rod (A) and canopy (B).

CONNECTING THE WIRES (Fig. 2)

5. Connect the electrical wires as shown in Fig. 2, making sure that all wire connectors (E) are secured. If your junction box has a ground wire (green or bare copper), connect the fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to the mounting plate (G) using the green screw provided.

FINISHING THE INSTALLATION (Fig. 1)

- 6. Place canopy (B) over mounting plate (G) and secure with mounting screws (F).
- Install (3) three medium base bulbs (L) up to 75 watts each or CFL or LED equivalent (not included) in accordance with the fixture specification—DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!).
- 8. Align white washer (H) and glass diffuser (I) to the bottom center stem of fixture body (C).
- 9. Use decorative washer (J) and cap (K) to secure the glass diffuser (I) to fixture body (C).
- 10. The glass diffuser (I) can be adjusted if necessary.

IMPORTANT: FIXTURE SHOULD BE INSTALLED BY A QUALIFIED ELECTRICIAN TO ENSURE PROPER WIRING AND INSTALLATION.

Your installation is now complete. Return power to the junction box and test the fixture.





